


3-Way Butterfly Valve Configuration



M = Master Valve/
Actuator Location
S = Slave Valve

N.O. = Normally Open
N.C. = Normally Closed